

Privacy by	🗹 Safe	Sub	scril	besм
For Email N	larketing	vou	can	trust

HOME

KSR Publishing, Inc. Copyright & 2015

- Minimize the use of plastic or non-absorbent packaging materials or aids.
- Properly position instruments in sets in a manner that will prevent holding of moisture.
- Be certain to clean the sterilizer chamber drain thoroughly, keeping it free of lint and other debris.
- Strive to keep the instrument set weight at no more than 25 pounds heavy sets are difficult to dry without increasing dry time.
- Maintain a record of all wet loads or instruments sets:
 - Note load contents.
 - Identify wet sets and packages.
 - Note day and time of cycle.
 - Confirm proper cycle parameters were achieved.
 - What were the results of sterilizer monitors, CI, BI, BD etc.? (This information may be useful in identifying patterns in failure and corrective actions required.)
 - Always follow the instructions for use (IFUs) of the medical device, sterilizer, containment and packaging manufacturers.

Q I understand that the instruments in a tray should not weigh more than a total of 25 pounds. This, however, is not always something that can be realistically achieved. We even have some single instruments that in and of themselves weigh close to or more than 25 pounds. I have been an OR nurse for many years and sets heavier than 25 pounds have been used with no problems. I have monitored some of our heavier sets and instruments with multiple BIs, CIs and even culturing. Every test we have conducted has passed and we are confident that our sterilization process has been effective. So I see no problem with what we are doing. There is more to sterilization than a weight number. There is no way that every set can be no more than 25 pounds. Would you agree? What are we supposed to do?

A Both the Association of periOperative Registered Nurses (AORN) and the Association for the Advancement of Medical Instrumentation (AAMI) recommend that instrument sets and trays prepared for sterilization not exceed 25 pounds. This weight limit includes the combined weight of the instruments, tray, basket, containment device and packaging materials. You are correct in saying that there is a lot more to successful sterilization than just the weight of an instrument set but this recommended weight limit of 25 pounds is also about more than effective sterilization. There are employee safety issues associated with the 25-pound weight limit to consider as well. Excessive weight increases the risk of ergonomic injury to personnel lifting and handling these sets. Also, excessive instrument weights and metal mass are prone to moisture retention and are a contributing factor to wetness in sterilized packages. Internal moisture can wick through package providing a conduit for contaminant penetration. There will obviously be times when it will be necessary to process and sterilize heavier instruments and sets. In these instances, measures should be taken to effectively manage this process for sterility assurance and worker safety. HPN

Ray Taurasi is Eastern Regional Director of Clinical Sales and Services for <u>Healthmark</u> <u>Industries</u>. His healthcare career spans over three decades as an Administrator, Educator, Technologist and Consultant. He is a member of AORN, AHA, SGNA, AAMI and a past president of IAHCSMM. Taurasi has been a faculty member of numerous colleges teaching in the divisions of business administration and health sciences.

Û

Midmark Mobile Instrument Service Multisorb Technologies Olympus America 4K UHD Olympus America Reprocessing One Source OR Specific Pegasus Medical Ruhof Corporation Vizient

Kev Surgical